
ACEBEAM
Light Where You Want It


User Manual




E65


HIGH-OUTPUT EDC FLASHLIGHT

PRODUCT OVERVIEW



Insulating film
Before first use, unscrew the tail switch and remove the insulating film.





USB-C charging

BATTERY INDICATOR

Battery>20%: Green
Battery 10%-20%: Red
Battery<10%: Red Flash

ACCESSORIES

1xE65 Flashlight; 1xACEBEAM 18650 Battery
1xLanyard; 1xUser Manual;
1xUSB-C Charging Cable;
1xQualification Certificate; 1xWarning Card

FEATURES

High-Performance Main White LED
- Equipped with a single SFT-60-W LED featuring new-generation vertical chip technology.
- Buck constant-current circuit with non-PWM dimming delivers stable, uniform, flicker-free output during extended use.
- Output up to 3,600 lumens and beam distance up to 580 meters, ideal for hiking, camping, backcountry route-finding, and similar activities.

Side Light Design
- Red side light with two adjustable levels.

USB-C Charging & High-Capacity Battery
- Convenient USB-C charging.
- Includes one 18650 3800mAh high-capacity battery.
- Replaceable battery design, simply swap in a fresh cell when power runs low.

Dual-Switch Design
- The main switch controls power, brightness adjustment, and switching between the main light and side light.
- The auxiliary switch provides one-step access to Turbo/Strobe.

Rugged Body
- AL6061-T6 aluminum alloy, CNC-machined and hard-anodized.
- 4.1mm body thickness for high strength, light weight, wear resistance, and impact resistance.
- Efficient copper base plate enables rapid heat conduction.
- IP68 dust and water protection for rain and splashes.
- 1.5-meter drop-tested to withstand accidental drops and impacts.

Specifications
Dimensions: 153.3mm/6.04" (length) x 27.5mm/1.08" (body diameter) x 36mm/1.42" (head diameter)
Weight: 229.2g/8.08oz

TECHNICAL PARAMETER

	SFT-60-W LED							Red	
FL1 STANDARD	Turbo	High	Med2	Med1	Low	Ultra Low	Strobe	High	Low
	3600~1000 ~150~50lumens	1000~150 ~50lumens	430~150 ~50lumens	150~50 lumens	50 lumens	8 lumens	3600~1000 lumens	5 lumens	1 lumen
	60s+1h28min+1h 40min+1h20min	1h34min+ 1h40min+1h20min	4h40min+ 40min+1h20min	14h10min +1h20min	42 h	215 h	60s+ 2h50min	12.5h	60h
	580m	314m	206m	134m	91m	25m	580m		
	84100 cd	24649 cd	10609 cd	4489 cd	2070 cd	156 cd	84100 cd		
	2m				1.5m				

Notice: The above-mentioned parameters have been measured in accordance with the international flashlight testing standard ANSI/PLATO FL1, and are approximate and may vary from flashlights, batteries, and environments. If you have any questions, please contact customer service.

OPERATIONS

Main Switch
Single press: On/Off.
Long press (while off): Hold for 1s to enter Ultra Low on the main light.
Long press (while on): Cycle through settings. Main light (white): Low–Med 1–Med 2– High; side red light: Low–High.
Double press: Switch between the side light and main light.
Quadruple press: Lock/unlock.
Auxiliary Switch
Single press: Main light Turbo; press again to return to the previous state (the side red light will not be restored).
Long press: Main light Strobe.

WARNING

1. Before use, carefully read the user manual and warning manual included in the packaging, and ensure full understanding and compliance.
2. It is recommended to use qualified batteries equipped with circuit protection.
3. Never shine the flashlight directly into eyes or onto skin when illuminated, to avoid vision damage or skin burns. Keep out of reach of children.
4. Users must operate in accordance with local laws, regulations, and relevant precautions. The manufacturer and seller shall not be held liable for any legal issues arising therefrom.

MAINTENANCE & NOTES

1. Do not disassemble any components by yourself, as this will void the warranty and may damage the flashlight.
2. Prolonged operation at maximum brightness will generate and rapidly conduct significant heat. Therefore, heating during use is normal.
3. With extended use, the lubricant on the tail threads may diminish. To maintain smooth threading, apply specialized lubricant promptly.
4. Over time, the flashlight's O-rings may deteriorate. Replace them periodically to \ preserve the waterproof integrity.
5. Regularly clean the flashlight's electrical contact surfaces to ensure proper operation. If abnormal flickering or failure to turn on occurs, it may be due to dirty contacts. Try cleaning them with an alcohol swab.
6. Lithium batteries may undergo self-discharge. For long-term storage, remove the battery and recharge it at least once every four months.
7. This flashlight offers excellent waterproof performance but is not intended for professional diving use.

PRODUCT WARRANTY

1. If the customer experiences any problems with an Acebeam product within 15 days of purchase, the dealer will replace that product.
2. If an Acebeam flashlight fails during normal use within aperiod of 10 year of purchase, the dealer will repair or replace the flashlight with the same or similar model.
3. The battery comes with a one-year(12 months) warranty from date of purchase. And the warranty does not cover additional accessories.
4. The warranty does not cover damage or failure caused by:
   A. Rough usage or operation which does not comply with the user manual or product specifications.
   B. Unauthorized disassembly, repair or modification.
      Defects or damaged caused by factors out of Acebeam's control.
   C. Battery leakage damaged products.
5. If there are any questions about ACEBEAM products, please consider the warranty and contact Acebeam or your original Acebeam dealer for warranty return instructions.

Email: cs@acebeam.com

DISCLAIMER CLAUSE

Acebeam is not liable for damages or injuries sustained resulting from the usage of the product inconsistent with the warnings in the manual.


www.Acebeam.com FB: AcebeamWorld FB Group: acebeam

ACEBEAM TECHNOLOGY CO., LIMITED
SHENZHEN ZENBON TECHNOLOGY CO., LTD
+86 0755 23036551
www.acebeam.com
cs@acebeam.com
3/F, No.2 Building, Yijiayang Industrial Park, Dalang, Longhua, Shenzhen 518100, Guangdong, China

Copyright © ACEBEAM. All rights reserved.
Powered by Acebeam Technology Co.,Ltd

ACEBEAM
Light Where You Want It

说明书




E65


强光户外EDC手电筒

产品概览



取出绝缘片
首次使用前，请拧下头部并取出绝缘片。





USB-C充电

产品特性

高性能主灯LED
- 搭载单颗SFT-60-W LED，新一代垂直芯片技术
- 降压恒流电路，非 PWM 调光，长时间使用时输出稳定、均匀，无频闪
- 输出可达3600流明，射距可达580米，适合徒步、露营、野外路线寻找等

侧灯设计
- 红光侧灯，两档可调

机身USB-C充电&大容量电池
- 机身USB-C便捷充电
- 标配单节 18650 3800mAh 高容量电池
- 电池为可更换设计，电量不足时可直接更换新电池

双开关设计
- 主开关负责开关、亮度调节、主灯侧灯切换
- 辅开关可一键进入极亮/爆闪模式

硬核机身
- AL6061-T6铝合金材质，CNC加工，硬质阳极氧化处理
- 筒身壁厚 4.1mm，具有高强度、轻量、耐磨和抗冲击特性
- 采用高效铜基板快速导热
- IP68 级防尘防水，可应对雨天、溅水等环境
- 机身经 1.5 米跌落测试，可承受意外跌落和冲击

产品规格
尺寸：153.3mm（长）x 27.5mm（筒身直径）x 36mm（头部直径），重量：229.2克

包装清单

1x E65手电；1x 18650电池；1x USB-C充电线；1x 手绳；1x 用户手册；1x 保修卡；1x 合格证

电量指示灯

电量>20%：亮绿灯
电量 10%-20%：亮红灯
电量<10%：红灯闪烁

性能参数

	SFT-60-W LED							红灯	
FL1 STANDARD	极亮	高亮	中亮2	中亮1	低亮	极低亮	爆闪	高亮	低亮
	3600~1000 ~150~50流明	1000~150 ~50流明	430~150 ~50流明	150~50 流明	50 流明	8 流明	3600~1000 流明	5 流明	1 流明
	60秒+1小时28分钟 +1小时40分钟+1小时20分钟	1小时34分钟+1小时 40分钟+1小时20分钟	4小时40分钟+ 40分钟+1小时20分钟	14小时10分钟 +1小时20分钟	42 小时	215 小时	60秒+ 2小时50分钟	12.5 小时	60 小时
	580米	314米	206米	134米	91米	25米	580米		
	84100 坎德拉	24649 坎德拉	10609 坎德拉	4489 坎德拉	2070 坎德拉	156 坎德拉	84100 坎德拉		
	2米				1.5米				

注：以上数据按照国际手电筒测量标准ANSI/PLATO FL1所述之测量方法，使用1节ACEBEAM 18650电池，为ACEBEAM实验室实测，具体使用需要根据实际环境而定，如有疑问请联系客服。

操作步骤

主按键
单击: 开/关机。
长按（关机时）： 长按1S进入主灯极低亮。
长按（开机时）： 切换档位。主灯白光，低-中1-中2-高；侧灯红光，低-高。
双击:切换侧灯/主灯。
四击: 锁定/解锁。

辅按键
单击: 主灯极亮。再次单击回到之前状态(红灯状态不恢复)。
长按: 主灯爆闪。

警告

1. 使用前先详细阅读包装内的说明书和警告标签，并确定已经熟知并遵守。
2. 推荐使用合格且带有电路保护的电池。
3. 严禁在手电点亮时直接照射眼睛及皮肤，以免造成视力损伤或皮肤灼伤，并远离儿童。
4. 使用者需按当地法律法规及相关注意事项操作，出现任何法律问题与制造商及销售商无关。

保养及注意事项

1. 请勿自行拆卸部件，否则将会导致保修失效并可能损手电。
2. 灯具长时间以极亮档位工作会积累大量的热量并及时导出，因此手电使用中发热是正常现象。
3. 长期使用，手电筒尾部螺纹的润滑脂会减少，为了保持螺纹顺滑，请及时使用专业润滑脂来润滑螺纹。
4. 长期使用后，手电的防水圈可能会老化。请您及时更换防水圈以维持手电的防水性能。
5. 请及时清洁手电的导电接触面以保证手电的正常工作，尤其是当手电出现异常的闪烁或者无法点亮的时候，有可能是接触面有污渍导致，尝试用酒精棉签清洁导电接触面。
6. 由于锂电池会自放电，所以建议您在长期不使用手电时将电池取出，并至少每4个月为电池充电一次。
7. 此手电防水效果优良，但不可作为专业潜水手电使用。

售后/保修条款

1. 15天保换：ACEBEAM产品自售出日起15天内，在正常使用的情况下，如有任何质量问题，均可向经销商要求免费更换。
2. 保修10年：ACEBEAM产品自售出日起10年内，在正常使用的情况下, 如有任何质量问题，均可享受免费维修服务。
3. 电池类产品保修期为1年，产品附加配件不在保修范围内。
4. 本条款不适用于以下情况：
   A: 人为破坏，拆解，改装本产品；
   B: 错误操作导致产品损坏（如电池装反等）；
   C: 电池漏液导致产品损坏。
5. 如对ACEBEAM产品有任何疑问请参照保修条款并联系当地代理商或发邮件到cs@acebeam.com.

免责条款 Acebeam 对因不按照手册中的警告使用产品而造成的损害或伤害不承担任何责任。

www.Acebeam.com FB: AcebeamWorld FB Group: acebeam

深圳市纵邦科技有限公司
+86-755-23036551
www.acebeam.com
cs@acebeam.com
深圳市龙华新区大浪街道华韵路300号仪佳扬工业园2栋3层

Copyright© ACEBEAM.
深圳市纵邦科技有限公司有对本说明书内容的最终解释权和修改权