

铜版纸157克, 双面印刷, 尺寸175x95mm, 四折五页, 风琴折



User Manual



Keylite 500
USB-C Keychain Light

FEATURES

POWERFUL BEYOND ITS SIZE

- As small as your finger, measuring 2.38 in x 0.63 in x 0.41 in and weighing only 19g (0.67oz).
- Reaches up to 500 lumens with a distance of 70 meters.

CONVENIENT CHARGING

- USB-C recharging, back to full power in about 1 hour; providing up to 12 hours of use (Moonlight mode)
- Monitor your power levels with a battery indicator.

DURABLE CONSTRUCTION

- IP66 rated for dust-tight protection and resistance against powerful water jets.
- Can withstand drops from up to 1.5 meters, ensuring reliability in tough environments.

IN THE BOX

1xKeylite 500 Flashlight; 1xUSB-C Cable; 1xLanyard; 1xUser Manual

TECHNICAL PARAMETER

FLI STANDARD	Turbo	High	Med	Low	Moonlight	Strobe	
	500~260 ~50lumens	200~150 ~20lumens	60~20 lumens	10 lumen	1 lumen	500 lumens	
	20s+5min +35min	3min+15min +42min	25min +80min	4h	12h	70min	
	70m		1225cd		IP66		1.5m

Notice: The above-mentioned parameters have been measured in accordance with the international flashlight testing standard ANSI/PLATO FL1, and are approximate and may vary from flashlights, batteries, and environments.

OPERATING INSTRUCTION

Lock/Unlock

Lock: While off, press and hold the switch for 3 seconds; the indicator will flash alternately, locking the flashlight. Once locked, pressing the switch will cause the indicator to flash 3 times to indicate that it is locked.

Unlock: In the locked state, double press the switch to unlock and enter memory mode.

Cycling Mode

While off, single press the switch to activate memory mode (defaulting to the previous brightness level used). Long press the switch for 0.7 seconds to decrease brightness, cycling through High, Med, and Low.

Moonlight Mode: While off, long press for 1 second to enter moonlight mode. Long press the switch for 0.7 seconds to enter cycling mode.

Turbo Mode: Double press the switch to enter Turbo mode. Long press the switch for 0.7 seconds to decrease brightness, entering cycling mode. A single press will turn it off.

Strobe Mode: Triple press the switch to enter strobe mode. A single press will turn it off.

BATTERY INDICATOR

Green light stays on for 3s: >30%
Red light stays on for 3s: 30%~10%
Red light flashes: <10%

WARNING

- By using this device, you certify you have read the included User Manual and Warning Card and release the manufacturer and retailers from all liabilities.
- Please use in accordance with applicable laws and regulations.
- Keep out of reach of children.
- DO NOT shine the light directly into human eyes. This may cause temporary blindness, or permanent damage to the eyes.
- DO NOT cover the light head when the flashlight is on, or place the flashlight head on the ground. The radiation energy of the flashlight may cause damage to the flashlight itself, or even result in burning to other materials.
- DO NOT modify/disassemble the light, otherwise the user will be in charge of the all responsibility.
- When the flashlight is working on the high mode, the surface temperature can reach 50°C. Please switch off the flashlight temporarily or turn it to low mode.
- Please use turbo mode with caution, Turbo greatly reduces the runtime and leads to high temperature on the flashlight surface.
- DO NOT use the turbo mode continuously when the environmental temperature is high in case the flashlight body is too hot to hold.
- When the product is used in a low-temperature environment, please try and keep it warm. If the temperature is too cold, it may not reach the highest output.
- If the product is left unused or carrier and transported, please lock the button to avoid accidentally activating the flashlight.
- Please keep the front lens clean. Due to radiation energy, it may heat up foreign matter on the lens which can potentially cause damage.
- Quality batteries with circuit protection will reduce the potential risk.

USAGE AND MAINTENANCE

Unauthorized disassembly may damage the light and void the warranty.

PRODUCT WARRANTY

- If the customer experiences any problems with an Acebeam product within 15 days of purchase, the dealer will replace that product.
 - ACEBEAM products with a built-in, non-removable battery are covered for 2 years warranty from the date of purchase. If any quality issues arise during normal use, customers can receive free repair service.
 - The warranty for the built-in battery is 2 years, and accessories are not covered under the warranty.
 - The warranty does not cover damage or failure caused by:
 - Rough usage or operation which does not comply with the user manual or product specifications.
 - Unauthorized disassembly, repair or modification. Defects or damaged caused by factors out of Acebeam's control.
 - Battery leakage damaged products.
 - If there are any questions about ACEBEAM products, please contact the warranty and contact Acebeam or your original Acebeam dealer for warranty return instructions. Email: info@acebeam.com
- Acebeam is not liable for damages or injuries sustained resulting from the usage of the product inconsistent with the warnings in the manual.

ACEBEAM TECHNOLOGY CO., LTD

+86-0755-23036551 | www.acebeam.com | info@acebeam.com

3/F Na2 Building, Yijayang Industrial Park, Dalang, Longhua, Shenzhen 518100, Guangdong, China

Copyright © ACEBEAM. All rights reserved.
Powered by Acebeam Technology Co., Ltd.



说明书



Keylite 500
USB-C钥匙扣手电筒

产品特性

小身材, 大能量

- 迷你紧凑设计, 尺寸为60.5毫米x16毫米x10.5毫米, 重量仅19克
- 最高亮度 500流明, 照射距离达 70米

便捷充电

- USB-C 充电, 大约1小时充满, 可提供长达12小时的续航(月光模式)
- 配备电量指示灯, 随时掌握剩余电量

坚固耐用

- IP66 防护等级, 防止灰尘进入, 并能抵御强劲水流
- 可承受 1.5米 高度跌落, 恶劣环境下依然可靠

包装清单

1xKeylite 500 手电; 1xUSB-C充电线; 1x手绳; 1x说明书

性能参数

FLI STANDARD	极亮	高亮	中亮	低亮	月光	爆闪	
	500~260 ~50流明	200~150 ~20流明	60~20 流明	10 流明	1 流明	500 流明	
	20秒+5分钟 +35分钟	3分钟+15分钟 +42分钟	25分钟 +80分钟	4小时	12小时	70分钟	
	70米		1225坎德拉		IP66		1.5米

注: 以上数据按照国际手电筒测量标准ANSI/PLATO FL1所述之测量方法, 以上数据为ACEBEAM实验室实测, 具体使用需要根据实际环境而定, 如有疑问请联系客服。

操作步骤

锁定/解锁

锁定: 关机状态下, 长按按键3秒, 指示灯交替闪烁, 手电筒锁定。单击按键时, 指示灯闪烁3次, 提示已锁定。

解锁: 锁定状态下, 双击按键, 解锁并进入记忆档。

循环档模式: 关机状态下, 单击按键, 开启记忆档(默认上次开启亮度), 长按按键0.7秒降档, 循环降档为高亮-中亮-低亮。

月光档: 关机状态下, 长按1秒进入月光档模式, 长按按键0.7秒进入循环档模式, 单击按键关机。

极亮档: 双击按键进入极亮档模式, 长按按键0.7秒降档, 进入循环档模式, 单击按键关机。

爆闪: 三击按键进入爆闪模式, 单击按键关机。

电量提示

绿灯常亮3s > 30%
红灯常亮3s: 30%~10%
红灯闪烁: < 10%

警告

- 本产品亮度高, 请勿直视发光体, 以免造成视力损伤。
- 建议成人或在成人监督下使用本产品, 请将本品放在儿童不能接触的地方。
- 本产品长时间工作后会累积大量热量, 造成产品外壳温度高, 请小心使用, 以免烫伤。
- 切勿在手电工作时近距离照射物体表面或头部朝下放置, 以免温度过高引发生危险。
- 请勿将手电浸入海水或其他腐蚀性介质中, 否则会导致损坏。

保修及注意事项

请勿自行拆卸部件, 否则将会导致保修失效并可能损坏手电。

售后/保修条款

- 15天退换: ACEBEAM产品自售出日起15天内, 在正常使用情况下, 如有任何质量问题, 均可向经销商要求免费更换;
 - 2年免费保修: ACEBEAM有内置电池且不能拆卸的产品自售出日起2年内, 在正常使用的情况下, 如有任何质量问题, 均可享受免费维修服务;
 - 内置电池保修期为2年, 产品附加配件不在保修范围内;
 - 本条款不适用于以下情况:
 - 人为破坏, 拆解, 改装本产品;
 - 错误操作导致产品损坏;
 - 电池漏液导致产品损坏。
 - 终身有限保修: 因不当使用引起的产品损坏, 或已超出免费保修时间的产品, 我司将提供有偿保修, 费用以实际更换费用为准, 不另收取人工费用。
- 如对ACEBEAM产品有任何疑问, 欢迎联系当地代理商或发邮件到 info@acebeam.com.

免责条款: Acebeam对因不按照手册中的警告使用产品而造成的损害或伤害不承担任何责任。



深圳市纵邦科技有限公司
+86-755-23036551
www.acebeam.com
info@acebeam.com

深圳市龙华新区大浪街道华韵路300号佳扬工业园2栋3楼

Copyright © ACEBEAM.
深圳市纵邦科技有限公司有对本说明书内容的最终解释权并修改权

