


铜版纸157克, 双面印刷, 尺寸301x95mm, 四折五页, 风琴折

ACEBEAM
Light Where You Want It

User Manual



Terminator M1 2.0

Multi-Light Zoomable LEP Flashlight

FEATURES

Multi-Light System

- Dual-head, multi-light source: LED flood + LEP throw + LED & LEP combo + tactical red light
- LEP zoomable, adjusting the beam precisely as needed
- Red light ideal for tactical concealment and low-impact night camping

Control System

- Rotary magnetic switch – quickly toggle between 5 modes: Lock/LEP throw/LED flood/Red/ LED & LEP Combo
- Dual-switch design: tail switch for instant turbo, side switch for power on/off and mode changes

Power & Charging

- High-capacity 21700 5600mAh battery, delivers extended runtime for demanding tasks
- Replaceable battery, swap in a spare to back to full power, no waiting for recharge
- USB-C metal charging port cover, more durable
- Battery level indicator, checking remaining power at a glance

Portability & Dimensions

- Includes a holster for convenient carry
- Dimensions: 109.5mm / 4.31" (L) x 35.2mm / 1.39" (W) x 63.35mm / 2.49" (H)
- Weight: 323.08g / 11.4 oz

Rugged Protection

- Aerospace-grade AL6061-T6 aluminum body with hard-anodized finish, drop-resistant up to 1 m
- IP68 waterproof rating, dustproof and reliable in rain, sand, or harsh weather

INCLUDED

1 x M1 2.0; 1 x 21700 Battery; 1 x USB-C Charging Cable; 1 x Holster; 1 x Diffuser Cap; 1 x Lanyard; 2 x Waterproof O-rings; 1 x User Manual; 1 x Warranty Card; 1 x Qualification Certificate; 1 x Warning Card

TECHNICAL PARAMETER

4xLEDs								
ANSI PLATO FL1	Turbo	High	Med2	Med1	Low	Ultra Low	Strobe	
3900~1000 lumens	1000 lumens	500 lumens	150 lumens	50 lumens	2 lumens	3900~1000 lumens		
3min+ 2h50min	3h	6h	20h	42h	9.5days			
1620m	82m	55m	30m	20m		160m		
6400cd	1681cd	756cd	225cd	100cd		6400cd		

LEP					RED				
ANSI PLATO FL1	Turbo	High	Low	Strobe	Turbo	High	Low	Strobe	
850~400 lumens	300 lumens	100 lumens	850~400 lumens	70 lumens	30 lumens	15 lumens	70 lumens		
3min+ 2h	3h	6.5h		7h	16h	330h			
1620m	1095m	668m	1620m	25m	21m	11m	25m		
656100 cd	299756 cd	111556 cd	656100 cd	156 cd	110 cd	30 cd	156 cd		

LEP+LED				
ANSI PLATO FL1	Turbo	High	Low	Strobe
3400~1100 lumens	1100 lumens	350 lumens	3400~1100 lumens	
2min+ 1h35min	1h	4h		
1580m	850m	668m	1580m	
624100 cd	180625 cd	111556 cd	624100 cd	

	2 meters	1 meter
--	----------	---------

Notice: The above-mentioned parameters (tested with 1 x ACEBEAM 21700 battery) have been measured in accordance with the international flashlight testing standard ANSI PLATO FL1, and are approximate and may vary from flashlights, batteries, and environments. If you have any questions, please contact customer service.

OPERATING INSTRUCTION

Mode Selection (Magnetic Control Ring, Left -> Right)

Lockout Mode, LEP Mode, LED Mode, Red Light Mode, LEP + LED Combo

Mode

Side Switch

Single Press: On/Off (memorized setting)

Double Press: Turbo; double press again to switch to Low (in LED mode, switches to memorized brightness level)

Triple Press: Strobe


Long press: When off, enters Ultra Low mode (only in LED mode); when on, cycles through brightness levels

Tail Switch

In any light mode, instant turbo; half press for momentary Turbo; full press to lock turbo.


INSULATING FILM

Remove the insulating film before first use



BATTERY INSTALLATION

Make sure the positive (+) end points toward the head



BATTERY VOLTAGE WARNING

Green light: >20%
Red light: among 20%~10%, low battery warning
Red flash light: <10%


WARNING

1. CAUTION! Possible dangerous radiation! Don't look into the light! May be dangerous for your eyes.
2. By using this device, you certify you have read the included User Manual and Warning Card and release the manufacturer and retailers from all liabilities.
3. Please use in accordance with applicable laws and regulations.
4. Quality batteries with circuit protection will reduce the potential risk.
5. Do not aim this light directly at eyes or exposed skin to prevent injuries. Keep this flashlight out of the reach of children.

USAGE AND MAINTENANCE

1. Unauthorized disassembly may damage the light and void the warranty.
2. This is normal case the light will accumulate a lot of heat when used on Turbo output levels for extended periods.
3. Lubricate the threads with professional grade lubricant regularly.

USB-C CHARGING INDICATOR



Red: Charging
Green: Fully charged

LOW-VOLTAGE WARNING

With the lamp switched on, and the voltage drop below 10%, the lamp is programmed to Ultra-Low, to remind you to charge/replace the battery. When the 21700 battery voltage drops below 2.7V, the lamp will turn off automatically.

4. Please swap out the O-rings regularly to maintain the water resistance level.
5. Maintain and keep clean any contact surfaces of the flashlight with alcohol swab. This may prevent irregular flashes during use.
6. Remove batteries during storage. Keep lithium-ion batteries charges approximately every 4 months.
7. This flashlight may not be used as diving light.

PRODUCT WARRANTY

1. We replace any quality defective lights within 15 days of purchase.
2. We offer warranty within 10 years of purchase if problems develop with normal use for LED model, 3 years for LEP model.
3. Limited lifetime warranty, we charge for replacement parts.
4. The warranty does not cover damage or failure caused by:
 - A. Rough usage or operation which does not comply with the user manual or product specifications.
 - B. Unauthorized disassembly, repair or modification. Defects or damaged caused by factors out of Acebeam's control.
 - C. Battery leakage damaged products.
5. If there are any questions about ACEBEAM products, please consider the warranty and contact Acebeam or your original Acebeam dealer for warranty return instructions.
Email: info@acebeam.com

DISCLAIMER CLAUSE


Acebeam is not liable for damages or injuries sustained resulting from the usage of the product inconsistent with the warnings in the manual.



ACEBEAM TECHNOLOGY CO., LTD
+86-0755-23036551
www.acebeam.com
info@acebeam.com
3/F No.2 Building, Yijayang Industrial Park, Dalang,
Longhua, Shenzhen 518100, Guangdong, China
Copyright © ACEBEAM, All rights reserved.
Powered by Acebeam Technology Co., Ltd

ACEBEAM
Light Where You Want It

说明书



终结者M1 2.0

多光源LEP变焦手电筒

产品特点

多光源设计

- 双头设计，四种照明模式，LED泛光 + LEP聚光 + LED&LEP同开 + 战术红光
- LEP可调焦，光束随心调
- 红光模式：战术隐蔽，户外露营不扰扰

操控系统

- 旋转磁控，五档快速切换：锁定/LEP聚光/LED泛光/红光/LEP&LED同开
- 双按键设计：尾按一键极亮，侧按开关档位切换

供电与充电

- 21700 大容量电池，高强度续航更持久
- 可换电池设计，备用电池快速回电，告别充电等待
- USB-C金属充电口保护盖，更耐用
- 电量指示灯，电量状态一看便知

便携与尺寸

- 附赠手电套，随身携带手电更方便
- 尺寸：109.5mm(长) x 35.2mm (宽) x 63.35mm (高)
- 重量：323.08g

严防防护

- 航天级AL6061-T6铝合金机身，硬质氧化抗磨，防锈高度1米
- IP68防水，风雨沙尘不惧，稳定可靠

包装清单

1x 终结者M1 2.0; 1x ACEBEAM 21700 电池; 1xType-C充电线; 1x 布套; 1x 柔光罩; 1x 手电; 2x 防水O圈; 1x说明书; 1x 保修卡; 1x 合格证; 1x 警告卡

性能参数

4xLEDs								
ANSI PLATO FL1	极亮	高亮	中亮2	中亮1	低亮	极低亮	爆闪	
3900~1000 流明	1000 流明	500 流明	150 流明	50 流明	2 流明	3900~1000 流明		
39秒+ 2小时50分钟	3小时	6小时	20小时	42小时	9.5天			
160m	82m	55m	30m	20m		160m		
6400 坎德拉	1681 坎德拉	756 坎德拉	225 坎德拉	100 坎德拉		6400 坎德拉		

LEP					红光				
ANSI PLATO FL1	极亮	高亮	低亮	爆闪	极亮	高亮	低亮	爆闪	
850~400 流明	300 流明	100 流明	850~400 流明	70 流明	30 流明	15 流明	70 流明		
39秒+ 2小时	3小时	3小时		2小时	16 小时	330 小时			
1620m	1095m	668m	1620m	25m	21m	11m	25m		
656100 坎德拉	299756 坎德拉	111556 坎德拉	656100 坎德拉	156 坎德拉	110 坎德拉	30 坎德拉	156 坎德拉		

LEP+LED				
ANSI PLATO FL1	极亮	高亮	低亮	爆闪
3400~1100 流明	1100 流明	350 流明	3400~1100 流明	
2分钟+ 1小时35分钟	1小时	4小时		
1580m	850m	668m	1580m	
624100 坎德拉	180625 坎德拉	111556 坎德拉	624100 坎德拉	

	2米	1米
--	----	----

注：以上数据按照国际手电筒测量标准ANSI/PLATO FL1所述之测量方法，所用电池为1节ACEBEAM 21700电池，以上数据为ACEBEAM实验室实测，具体使用需要根据实际环境而定，如有疑问请联系客服。

操作步骤

模式选择（磁控旋钮，从左一右）

锁机模式、LEP模式、LED模式、红光模式、LEP + LED 组合模式

侧按键

单击：开/关（记忆档位）

双击：极亮，再次双击切换至低亮（LED模式切换至记忆档）

三击：爆闪

长按：关机时进入极低亮（仅LED模式下）；开机时循环切换亮度档位

尾按键

任何光源模式下，一键极亮，轻按点射，重按锁定极亮。

低电压指示

在开机状态下，该灯电量低于10%时，会自动降档至极低亮模式，以提示您电池电量即将耗尽，需要给电池充电或更换电池。



温馨提示

首次使用前，请拧下尾盖并取出绝缘片。



电池安装指示

确保插入电池时正负(+)端指向头部。



红色：显示正在充电
绿色：显示充满电

电量指示

绿色：大于20%；
红色：20%到10%之间，此时低电量提醒；
红色闪：小于10%；

警告

1. 使用前请先详细阅读包装内的说明书和警告标签，并确保已经熟知并遵守。
2. 推荐使用合格且带有电路保护的电池。
3. 严禁在手电点亮时直接照射眼睛及皮肤，以免造成视力损伤或皮肤灼伤，并远离儿童。
4. 使用者需按当地法律法规及相关注意事项操作，出现任何法律问题与制造商及销售商无关。
5. 禁止近距离直视本产品光斑，以免对眼睛造成伤害。

保养及注意事项

1. 请勿自行拆卸部件，否则会导致保修失效并可能损坏手电。
2. 灯具长时间以极亮档位工作会积累大量的热量并及时导出，因此手电使用中发热是正常现象。

3. 长期使用，手电螺纹的润滑脂会减少，为了保持螺纹顺滑，请及时使用专业润滑脂来润滑螺纹。
4. 长期使用后，手电的防水圈可能会老化。请您及时更换防水圈以维持手电的防水性能。
5. 请及时清洁手电的导电接触面以保证手电的正常工作，尤其是当手电出现异常的闪烁或者无法点亮的时候，有可能是接触面有污渍导致，尝试用酒精棉签清洁导电接触面。
6. 由于锂电池会自放电，所以建议您在长期不使用手电时将电池取出并至少每4个月为电池充电一次。
7. 此手电防水效果优良，但不可作为专业潜水手电使用。

售后/保修条款

1. 15天保换：ACEBEAM产品自售出日起15天内，在正常使用的情况下，如有任何质量问题，均可向经销商要求免费更换；
2. 10年免费维修：ACEBEAM LED类产品自售出日起10年内，在正常使用的情况下，如有任何质量问题，均可享受免费维修服务；
3. 特别注明：LEP类产品自售出日起3年内，在正常使用的情况下，如有任何质量问题，均可享受免费维修服务；
4. 本条款不适用于以下情况：
 - A: 人为破坏，拆解，改装本产品；
 - B: 错误操作导致产品损坏（如电池装反等）；
 - C: 电池漏液导致产品损坏。
5. 如对ACEBEAM产品有任何疑问请参照保修条款并联系当地代理商或发邮件到info@acebeam.com.

免责条款：Acebeam对因不按手册中的警告使用产品而造成的损害或伤害不承担任何责任。



深圳市纵邦科技有限公司
+86-755-23036551
www.acebeam.com
info@acebeam.com
深圳市龙华新区大浪街道华韵路300号佳扬工业园2栋3层
Copyright © ACEBEAM
深圳市纵邦科技有限公司有对本说明书内容的最终解释权 and 修改权